



# 4-step intallation guide for protracer

1

The "**Audio Connection Diagram**" is located on the back of the paper. You can complete your connection by reviewing this diagram. All other connection diagrams and manuals such as "TS EN 81-70 Led Connection Diagram", "Relay Connection Diagram", "User Manual" and "Web User Manual" can be found at "[www.protracer.com.tr/support](http://www.protracer.com.tr/support)".

2

Protracer works with SIM card. To use the web platform, you need a SIM card with a voice and Internet package (defined as "**static IP** or **static APN**"). Before inserting the SIM card into the device, first insert it into your mobile phone to make sure it connects to the internet and makes calls. **Then cancel the PIN code.**


3

To use the web platform, you can log in by clicking the "**Login**" button on [www.protracer.com.tr](http://www.protracer.com.tr). Here you can **create your elevators** and arrange which numbers to call. You can create your registration by clicking on "**Register**" button to get your username and password. Your information will be checked, then "**username**" and "**password**" will be sent to you as **SMS**.

4

You must first create your elevators by logging into the system. Then you can define the number from the corresponding menu. If you want to perform a number identification without using the web platform: Send an SMS from your mobile phone to the SIM card number installed in the device, that you want the device to call (as **TEL1 - country code - 10 digit phone number - \***). Example for Turkey : TEL**10090**1112223344\*

\*

We are waiting to help you in addition to all your questions, problems and comments on  **0090 850 577 88 28** Whatsapp Support Hotline. (Weekdays between 09:00 - 18:00)